### COMMONWEALTH OF AUSTRALIA

### DEPARTMENT OF TRANSPORT

### AIR\_TRANSPORT GROUP

### AIRWORTHINESS DIRECTIVE - GLIDERS

REF: GFA/AD/Slingsby 12/74

### Glider Types affected

Slingsby T59 Kestrel; all marks.

#### Background

Slingsby Technical Instruction No. 67 issue No. 2 gives details of a modification to reduce wear on the rudder actuator bearings. Wear in the actuator bearings leads to free play in the rudder; the maximum allowable total free play measured at the rudder trailing edge is 10 mm (%"). The following extract of Slingsby Technical Instruction No. 67 is included as part of this Directive.

### Procedure : ~

- Remove the rudder from the aircraft.
- 2. Disconnect the rudder pushrod from the rudder actuator at the point where it passes through the rear spar of the fin.
- 3. By undoing and removing the long bolt attaching the actuator to the lower rudder hinge remove the actuator from the aircraft.
- 4. Remove the two bolts which hold the two parts of the actuator together.
- 5. Check the diameter of these bolts. They will be 6 mm diameter for an aircraft with a German fitting and ‡" diameter for an aircraft with an English fitting. Before proceeding ensure that the modification kit supplied is for the correct type of fitting; see Parts List at the end of this Instruction.
- Modifications to existing parts.

German Fitting

(a) Remove the four existing bushes from the circular portion of the Shaped bracket and line ream these four holes to 10mm + 00. Press fit new bushes, Part No. T59A-03-14 into the bracket as shown on Drawing No. T59A-03-11.

- (b) Line ream the two short tubes at the end of the shaped bracket to .25" + .001 .000
- (c) Ream out the hole in the lower rudder attachment hinge on the fin rear spar to .25" + .0005

- English Fitting

  (a) Remove the four existing bushes from the circular portion of the Shaped bracket and line ream these four holes to .408" + .001. Press fit new bushes, Part No. T59A-03-13, into the bracket as shown on Drawing No. T59A-03-12.
- 7. The following parts are made redundant by the modification:-
  - German Fitting
    i) Short 6mm bolts 2 off with distance tubes if
     fitted.
  - ii) Shouldered distance tubes 2 off.
  - iii) Attachment bolt joining fitting to fuselage.
  - iv) Nuts and split pins from above.

# English Fitting

- i) Short 4" bolts 2 off with distance tubes.
- ii) Split pins.
- 8. The two brackets can now be re-assembled as shown on Drawing No. T59A-03-11 for a modified German fitting and T59A-03-12 for a modified English fitting.
- 9. Fit the actuator to the aircraft and reconnect the rudder pushrod. Check the control for freedom of movement and refit the rudder.
- 10. Check the rudder movement, this should be 25° to either side from neutral. (

### PARTS REQUIRED: -

### To modify a German Fitting

1.	Drawing No. T59A-03-11	
2.	Bush 59A-03-14	4 off
3.	Bush 59A-45-431	2 off
4.	Bolt 59A-45-444	2 off
5.	Bolt 3A-111/23E	1 off
6.	Nut 2A 110/ES	3 off
7.	Split Pins SP90/C6	3 off
8.	Thin Washer SP 126/E	1 off

# To modify an English Fitting

! . •	Drawing No. 59A-03-12	
2.	Bush 59A-03-13	4 off
3.	Bolt 59A-45-444	2 off
4.	Split Pins SP90/C6	3 off

A kit of parts may be obtained from Slingsby Sailplanes, Kirkbymoorside, York, YO6 6EZ, England.

## Compliance:

This modification is optional where free play at the rudder trailing edge is less than 10mm ( $\frac{3}{8}$ ") total. Where free play exceeds the above limit modification is mandatory. This Directive is issued pursuant to Air Navigation Regulations under the delegated authority of the Director-General of Civil Aviation.

Douglas Lyon

Chief Technical Officer Airworthiness

Gliding Federation of Australia

Date: 25th November, 1974

# Distribution:

Registered Owners of Slingsby T59 Gliders

E. Schneider Pty. Ltd.

D of T (A.W.O.R.) C.T.O/A

C.T.O/Ops.

R.T.O.s/A - (5 copies)

A.T.O.

R.Keane

G.Simpkins

G. Detto

R. Martin

D. Vanston

G.F.A. Secretary